FOR FILEBOXES - ASSEMBLY INSTRUCTIONS

TOOLS REQUIRED

 Powered Screwdriver with #2 Phillips-Head Tip



PARTS LIST

- 1. (12) Horizontal Crossbars
- 2. (04) Center Verticals
- **3.** (O2) Right Front & Left Rear Corner Verticals
- **4.** (O2) Left Front & Right Rear Corner Verticals
- **5.** (04) Front & Rear Grid Connecting Tubes
- 6. (04) Wall Mount Brackets
- 7. (18) Horizontal Sliderails


#2 #3 #5 #7

FASTENER LIST

- **1.** (92) #06 x 1/2" Fastening Screws
- **2.** (08) #10 x 1-1/4" Fastening Screws
- **3.** (08) Plastic Wall Anchors

NOTE:


Separate All Parts into Groups (as shown) and Familiarize. Read All Instructions Before Beginning Assembly




IMPORTANT: Do not install any fasteners until instructed!

Numbers in **BOLD** indicate item number from Parts/Fastener Lists.


FRONT GRID ASSEMBLY



Parts Needed: 6 of #1 2 of #2 1 of #3 1 of #4




6 Horizontal Crossbars (#1) inserted through 2 Center Verticals (#2) (holes facing down) Tip: When installing second Center Vertical, stand assembly with Horizontal Crossbars placed on floor and push down second Center Vertical to Alignment Dimples.




1 Left Front Corner Vertical (#4) and 1 Right Front Corner Vertical (#3) - Placed on Horizontal Crossbars (Holes Facing Down)

REAR GRID ASSEMBLY




Parts Needed: 6 of **#1** 2 of **#2** 1 of **#3** 1 of **#4**




6 Horizontal Crossbars (#1) inserted through 2 Center Verticals (#2) (holes facing up)

Tip: When installing second Center Vertical, stand assembly with Horizontal Crossbars placed on floor and push down second Center Vertical to Alignment Dimples.



1 Right Rear Corner Vertical (#4) and 1 Left Rear Corner Vertical (#3) - Placed on Horizontal Crossbars (Holes Facing Up)

SLIDERAIL ASSEMBLY



18 Horizontal Sliderails (#7) and 4 Front and Rear Grid Connecting Tubes (#5) inserted in Rear Grid

Tip: If Necessary, Tap Horizontal Slide Rails to be sure Slide Rails are Fully Inserted



Fastening Horizontal Sliderails (**#7**) in Rear Grid using 18 - #06 x 1/2" Fastening Screws (**#1**) *Tip: Start at top row and work down*

Note: One fastener per sliderail - bottom hole only




All Horizontal Sliderails fastened to Rear Grid. Now Fasten 4 Front and Rear Grid Connecting Tubes (#5) to Rear Grid using 4 - #06 x 1/2" Fastening Screws (#1) Note: Use One Fastener Only

IMPORTANT: Do not install any fasteners until instructed!

Numbers in **BOLD** indicate item number from Parts/Fastener Lists.

JOINING FRONT TO REAR GRID



Join Front to Rear Grid by inserting 4 Front & Rear Grid Connecting Tubes (#5) into Front Grid Assembly **Note: Do Not Fasten at This Time**



Insert and fasten 18 Horizontal Sliderails (#7) into Front Grid Assembly using 18 - #06 x 1/2" Fastening Screws (#1) Note: Fasteners in Bottom Hole Only, Work from Bottom Row to Top Row Making Sure All Tubes are Fully Inserted!




Turn unit upright and place firmly against wall where unit is to be mounted.

FASTENING VERTICALS & FRONT & REAR GRID CONNECTING TUBES



Fasten 4 Front & Rear Grid Connecting Tubes (#5) to Front Grid Assembly Using 4 - #06 x 1/2" Fastening Screws (#1)



Make sure unit is Straight and Square, and all Verticals are Pressed Firmly together and against alignment dimples



Fasten All Verticals to Horizontals Making sure all joints are pressed firmly together and tight against alignment dimples using 48 - #06 x 1/2" Fastening Screws (#1)

Note: Fasteners in Holes Facing YOU Only-

FASTENING BIN WAREHOUSE TO WALL



Place 4 wallmount brackets (**#6**) over 4 Rear Verticals above 2nd Horizontal Crossbar (**#1**) and fasten to wall using 8 - #10 x 1-1/4" Fastening Screws (**#2**)



Note: If mounting into Drywall or Masonry, mark & drill 1/4" holes and insert plastic wall anchors
- and proceed with step 1-



Unit <u>must</u> be attached to wall to keep from tipping over!